
Parkonect Sleep Mode

Parkonect Kiosk Related · https://qa.flashparking.com/docs/parkonect-sleep-mode/



With Sleep mode, the Parking Operator can place PARCS equipment in an inactive status, effectively preventing any parker from interacting with the device until it is enabled again, either manually or by schedule.

This feature is available for Entry and Exit kiosks, POFs, and Pedestrian Door in any form factor.

Sleep Mode

☐ Enabled

Schedule ○

Awake ◉

Sleep ○

Start Day	Start Time	End Day	End Time	
Tuesday	11:30 AM	Tuesday	11:45 AM	Delete

Start Day: Sunday

Start Time: 12:00 AM

End Day: Sunday

End Time: 12:00 AM

Add Time

	Title	Msg 1	Msg 2
Awake Message			
	☐	☐	☐
Sleep Message			
	☐	☐	☐


How To

In PK Admin, go to Garage > Garage Setting > Lanes > (select lane). Enable *Sleep Mode* then choose between one of these options: **Schedule**, **Awake**, and **Sleep**.

Schedule


Selecting this option allows for the creation of a custom schedule that includes start day and time, and end day and time, by which the kiosk will automatically go to the inactive status and “wake up” following the selected days and times. Note that multiple schedules can be created to accommodate any need.


1. Shows a created schedule that will take effect on the date and time selected.
2. Shows the default schedule creation options.



Awake


By selecting the Awake option and clicking the Update button, the kiosk will instantly go back to active during any inactive period. This includes if the kiosk was placed as inactive by a schedule or manually.






Sleep


Selecting the Sleep option and clicking the Update button will instantly place the kiosk as inactive, the kiosk will only be able to go back to operation by repeating the instructions shown above with the Awake option.


Messages
Printer
Update
Edit Text
Cancel
Sleep Mode
Enabled
Schedule
Awake
Sleep



Screen Text Messages

Below the schedule creation section is a set of boxes for making changes to Awake Message and Sleep Message on the screen. A Title, Message 1, and Message 2 can be placed, each taking one line on the kiosk screen.




Each message box can be toggled on or off by checking or unchecking the check box below each of them.


Implementation

Sleep Mode Module

1. In the Parkonect portal, go to the Parkonect dropdown and select Modules.




2. Select your garage from the dropdown.



3. Look for the Sleep Mode flag in the list that appears > check the Sleep Mode flag.




4. Click the Update button under the Garage selection section.




Sleep Mode Settings

1. In the Parkonect Portal, select the garage and click the Garage Settings option.



2. Select Lanes and click the kiosk to be configured with the Sleep Mode settings.



3. The Sleep Mode settings should be visible on the right-hand side of the kiosk configuration screen. Allowing you to configure any schedule or changes in sleep or awake to the kiosk by making changes and clicking the Update button.

