

# TD9000 Printer Programming Guide



# SysParc Programming Guide

---

This guide outlines the procedure to change programming of SysParc printers located in Parkonect systems. Parameters such as time/date and ticket information can be updated.

---



10-15min



-none-



It is advised to print a ticket from the machine for reference  
before beginning re-programming procedures

# Read Me First

---

Facing the front of the TD9000 unit remove the panel on the left side.

On the cover of SysParc board, in the lower left corner, is a rocker switch labeled, "Prog./Step". This rocker switch is used to navigate system menu and to select letter and numeric characters.



Advancing through the main menu can be done by pressing "Prog", which advances one option forward. To select an option to change, press "Step". You may notice symbols displayed on the screen, use the "Step" to clear the characters.

For a 'space' character, press "Step" twice.

Press the switch once and fully release to avoid accidental double step the advancement. There is no return, so if your desired character is missed, you will need to go through the complete alpha-  
bet and number sequence to return.

## Menu Layout:

Welcome Message > Set Date & Time > Set Display Message > Set Line 1 > Set Line 2 > Set Line 3 > Set Site



# 1. Set Date & Time

---

1. Press "Prog." and the screen will change from welcome message to "Set Date & Time".
2. Press "Prog" to enter edit mode.
3. Press "Prog" to display underscore.



4. Press "Step" until the correct month number is shown on the display.
5. Press "Prog" Once, the underscore will move one space to the right; under the day of the month number.
6. Press "Step", until the correct date is shown.
7. Press "Program", and the underscore will move one space to the right; to the year number.
8. Press "Step", until the correct year is shown.
9. Press "Program", and the underscore will move one space to the right; to the hour number.
10. Press "Step", until the correct hour appears (note: time is shown in military style).
11. Press "Step", until the correct minute is shown.
12. Press "Program" until you return to main menu.

## 2. Set Display Message

---

The display message is the message displayed on the LCD screen inside the terminal.

1. Press "Prog." The screen will change from welcome message to "Set Date & Time".
2. Press "Prog." until "Set Display Message" is shown. Press "Step" to enter edit mode.
3. Press "Step" to clear symbols
4. Press "Step" and the underscore will appear on the screen.



5. Press "Step" and the underscore will move one space to the right.
6. Press "Prog" to advance the letter character until you reach the correct character.
7. Repeat this process until you have spelled the correct word or phrase.
8. If you finish your entry before hitting character limit, continue to press "Step" until you reach the main menu.

# 3. Set Line 1-3

---

These are the three lines of text that will be printed on your tickets.

1. Press "Prog." The screen will change from welcome message to "Set Date & Time"
2. Press "Step" until "Set Line [1-3]" is shown. Press "Step" to enter edit mode.
3. Press "Step" to clear symbols
4. Press "Step" and the underscore will appear on the screen.



5. Press "Step" and the underscore will move one space to the right.
6. Press "Prog" to advance the letter character until you reach the correct character.
7. Repeat this process until you have spelled the correct word or phrase.
8. If you finish your entry before hitting character limit, continue to press "Step" until you reach the main menu.

# 4. Set Site

---

The correct site number must be entered for site in order for system to operate. Contact Parkonect support if you don't have site information.

1. Press "Prog." The screen will change from welcome message to "Set Date & Time"
2. Press "Prog" until "Set Site" is shown. Press "Step" to enter edit mode.



3. Press "Step" to advance to correct number (1-99). Hold "Step" to cycle up automatically.
4. Press "Prog" to select and to end programming.

# Questions?

Contact our support team!



**312-878-1220**



**Support@parkonect.com**